



Part
Sheet Title

NOTE: This book has been generated using HORIZONTAL images. For best results when printing, please select LANDSCAPE orientation on your printer.

.....

E023668-01	ACTUATOR ASSY, HOUSE DOOR, FLD
MP268335	ADJUSTER ASSY, BOOM SUSP
82002568	AIR CONDITIONER
S092858	AIR CONDITIONER SYSTEM
S068510-VG05	AIR FILTER BLOWER, FIELD ASSY
S093226	AIR LOCK FIELD ASSEMBLY
S092824	AIR LOCK ROOM STRUCTURE
S093225	AIR LOCK ROOM, INTERNAL FITTINGS
D030121	AIR SYSTEM - BOOM
62036987	AIRMOTOR
62054251	ALTERNATOR, AC GENERATOR
S025854	ARM ASSY, STABILIZER
S034012	ARM, WALKING, LEFT
S025845	ARM, WALKING, RIGHT
S079848	ASSEMBLY, CAP, BEARING
MP361002	ASSEMBLY, COLLAR
D030130	AUTO LUBE - OPEN GEAR
D030129	AUTO LUBE - ROPE SPRAYS
D030131	AUTO LUBE CONTROL CENTER
D030124	AUTO LUBE, MPG, ROTATING FRAME
D030127	AUTO LUBE-BOOM
D030128	AUTO LUBE-FAIRLEAD, FOOT PINS
D030126	AUTO-LUBE, TRI-STRUCTURE
S057453	BASE ASSY, FLD 75 FT
S057456	BASE SECTION, CENTER
S057012	BASE SECTION, OUTER ELEC 75 FT
S057393	BASE SECTION, OUTER RING 75 FT
S057497	BASE, WIRING AND CABLE DRAWER
S067557	BEAM, HOIST INTERMEDIATE
MP277525	BEARING BLOCK ASSY, FRONT
MP277526	BEARING BLOCK ASSY, REAR
S074305	BLOWER ASSEMBLY, DRAG
S074304	BLOWER ASSEMBLY, HOIST
S074306	BLOWER ASSEMBLY, PROPEL
S074307	BLOWER ASSEMBLY, SWING
E024054-01	BOOM LIGHT & POWER
D030197-01	BOOM SUSP.& PENDANT SUPPORT
S033427	BOOM, 360 FT, FIELD ASSY
S055457	BRACKET, BOOM
E023697-01	BRACKET, PENDANT



Part Sheet	Title
82130638	BRAKE ASSY,10.5KN,SINT,MTG KIT
82130639	BRAKE ASSY,30KN,STD,MTG KIT
82057777	BRAKE ASSY,36KN,SINT PAD, RH
82057778	BRAKE ASSY,36KN,SINT PAD,LH
D030123	BULK LUBE TANKS - FIELD ASSEMBLY
S076037	BULK LUBE TANKS ASSEMBLY
K990130-01	CAB, RH MECH/ELEC FLD ASSY
62055600	CABLE REEL, CRANE CONTROLS
S064635	CABLE, ADAPTER, BASE SIDE
62053208	CALIPER, NO PADS
S057115	CARRIER, STAGE 1, ADAPTER
S057495	CARRIER, STAGE 2, ADAPTER DRAWER
MP262552	CENTER JOURNAL,REV FRAME
62055228	CIRCUIT BREAKER, VACUUM
62055229	CIRCUIT BREAKER, VACUUM
62055230	CIRCUIT BREAKER, VACUUM
62055231	CIRCUIT BREAKER, VACUUM
62055232	CIRCUIT BREAKER, VACUUM
62055233	CIRCUIT BREAKER, VACUUM
62055234	CIRCUIT BREAKER, VACUUM
D028120-01	COLLAR ASSEMBLY
MP072401	COLLAR ASSEMBLY
MP072402	COLLAR ASSEMBLY
S081162	COLLAR ASSEMBLY
D029300-01	COLLAR ASSY,SPLIT
MP262547	COLLAR, SPLIT
MP263613	COLLAR, SPLIT, ASSEMBLY
17413493	COLLECTOR RING, AUXILIARY
K140087	COLLECTOR RING, MAIN, FIELD ASSY
D028934-01	COLLECTOR RING,AUX,FLD
D028933-01	COLLECTOR RING,MAIN,SHOP ASSY
12089099	COMPRESSOR,AIR
S060010	CONSOLE ASSY, COMPUTER/DISPLAY
S023822	CONSOLE ASSY, LH
S023821	CONSOLE ASSY, RH
S023819	CONSOLE, CONTROL & SEAT
S023824	CONSOLE, CONTROL, MECH WITH SEAT
S023823	CONSOLE, ELECT CTRL INSTALLATION
S060015	CONSOLE, INTERNAL EQUIP
S023825	CONSOLE, NAMEPLATE INSTALL
17500448	CONTROL BOX, HYDRAULIC STAIR
12980044	CONTROL PANEL, REAR DOOR
62053966	CONTROL,CUBICLE



Part Sheet	Title
62053965	CONTROL,PILOT
S011940	COOLER SYSTEM, SWING, LH
S071559	COOLER SYSTEM, SWING, RH
A005280	COOLER, SWING OIL ASSY
S052739	COUPLING, GEAR
S068537	COUPLING, GEAR, FLEXIBLE
C119755-01	COUPLING, GRID, GEAR END
C119758-01	COUPLING, GRID, MOTOR END
S068538	COUPLING, HUB, BRAKE ROTOR
S052740	COUPLING, HUB, BRAKE ROTOR, PROPEL
S038144	COVER, ACCESS
S051815	COVER, ACCESS
82181829	COVER, ACCESS, 16 IN
S051740	COVER, BRAKE, LH
S051757	COVER, BRAKE, RH
82181827	COVER, FILL, 10 IN
82181828	COVER, FILL, 12 IN
S051820	COVER, HINGED
S051817	COVER, HINGED W/EXTENSIONS
S058303	COVER, HOIST ROPE OPENING
S056071	COVER, PROPEL GEARCASE, LH
S056072	COVER, PROPEL GEARCASE, RH
S059610	COVER, WELDED
S059611	COVER, WELDED
S059631	COVER, WELDED
S067873	COVER, WINCH
D030300-01	CRANE, JIB, ASSY, LUBE ROOM
E024000-01	CRANE, MAIN TRAVELING
MP498390	CYLINDER, HYDRAULIC
MP356328	CYLINDER, RETURN MECHANISM, SHOE
MP130669	CYLINDER, SPRING RETURN W/CPLG
E023684-01	DAMPENER, BOOM SUPPORT ROPE
12202194	DIESEL GENERATOR SET
MP144127	DIPSTICK, OIL GAUGE
MP146432	DIPSTICK, OIL GAUGE
S011841	DIRT CHUTE
A005928-01	DISPLAY,PROGRAMMED & MATERIAL
D029520-01	DOOR ASSY,DOUBLE
S062515	DOOR, HINGED, RH
S051811	DOOR, HINGED,LH
D029519-01	DOOR, LH, WELD & ASSY
D028828-01	DOOR,LH,W/GLASS
E024088-01	DPT/REACTOR WIRING