

Operation & Maintenance Manual

H45, H45s, H50, H50s, H63, H63s, H70, H70s, H90C, H90Cs, H100 & H100s Hydraulic Hammers

**H45 & H45s:
6CZ1-UP**

**H50 & H50s:
5MZ1-UP**

**H63 & H63s:
4GL122-UP**

**H70 & H70s:
4KL1033-UP**

**H90C & H90Cs:
6TZ1-UP**

**H100 & H100s:
4ML159-UP**

