



LUBRICATION & MAINTENANCE GUIDE

966 WHEEL LOADER

SERIAL	78G1-UP	42J2487-UP
NUMBERS	76J4144-UP	30K1253-UP
	25U1-UP	