

# Parts Manual

---

## **920 Wheel Loader**

---

**41J4371-Up (Vehicle)**  
**48V14492-Up (Engine)**  
**3DA1-Up (Transmission)**

