

# Parts Manual

---

## TH408D Telehandler

---

CJ41-UP (Engine)  
JKT1-UP (Engine)  
W231-UP (Engine)  
TH91-UP (Machine)  
TH41-UP (Machine)  
CF51-UP (Transmission)  
H5E1-UP (Transmission)  
HA51-UP (Transmission)  
SD31-UP (Transmission)

Powered By C4.4 or C3.4 Engine



Scan to find and purchase genuine Cat® parts and related service information.





# Product and Dealer Information

Note: For product identification plate locations, see the section "Product Identification Information" in the Operation and Maintenance Manual.

Delivery Date: \_\_\_\_\_

## Product Information

Model: \_\_\_\_\_

Product Identification Number: \_\_\_\_\_

Engine Serial Number: \_\_\_\_\_

Transmission Serial Number: \_\_\_\_\_

Generator Serial Number: \_\_\_\_\_

Attachment Serial Numbers: \_\_\_\_\_

Attachment Information: \_\_\_\_\_

Customer Equipment Number: \_\_\_\_\_

Dealer Equipment Number: \_\_\_\_\_

## Dealer Information

Name: \_\_\_\_\_ Branch: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Dealer Contact

Phone Number

Hours

Sales: \_\_\_\_\_

Parts: \_\_\_\_\_

Service: \_\_\_\_\_