

Parts Manual

TH357D Telehandler

CJ41-UP (Engine)
JKT1-UP (Engine)
W231-UP (Engine)
TD61-UP (Machine)
TD71-UP (Machine)
H5E1-UP (Transmission)
HA51-UP (Transmission)
SD31-UP (Transmission)
BK21-UP (Transmission)
H5E1-UP (Transmission)
H5F1-UP (Transmission)
HA51-UP (Transmission)
SD31-UP (Transmission)

Powered By C3.4 or C4.4 Engine



Scan to find and purchase genuine Cat® parts and related service information.



Product and Dealer Information

Note: For product identification plate locations, see the section "Product Identification Information" in the Operation and Maintenance Manual.

Delivery Date: _____

Product Information

Model: _____

Product Identification Number: _____

Engine Serial Number: _____

Transmission Serial Number: _____

Generator Serial Number: _____

Attachment Serial Numbers: _____

Attachment Information: _____

Customer Equipment Number: _____

Dealer Equipment Number: _____

Dealer Information

Name: _____ Branch: _____

Address: _____

Dealer Contact

Phone Number

Hours

Sales: _____

Parts: _____

Service: _____