Parts Manual

S3015, S3025, S3035 Demolition & Scrap Shears

LNP1-UP (S3015)

SX21-UP (S3015)

LNS1-UP (S3025)

SX31-UP (S3025)

LNT1-UP (S3035)

SX41-UP (S3035)





Product and Dealer Information

Note: For product identification plate locations, see the section "Product Identification Information" in the Operation and Maintenance Manual.

Delivery Da	ate:					
Produc	t Information					
Model:						
Product Ide	entification Number:					
Engine Ser	ial Number:					
Transmissio	on Serial Number:					
Generator	Serial Number:					
Attachment	Serial Numbers:					
Attachment	Information:					
Customer I	Equipment Number:					
Dealer Equ	iipment Number:					
Dealer	Information					
Name:	Branch:					
Address:						
	Dealer Contact	Phone Number	<u>Hours</u>			
Sales: -						
Parts: -						
Service: -						