

Tool Operating Manual

i08617108

M0110451 (NEHS1003) 132-1203 Lifting Bracket

SMCS Code: 0374; 0599; 0629; 0632; 0700; 3258

Off-Highway Truck/Tractor
All

Table of Contents

Introduction	1
Safety Information.....	1
Safety Signal Words	2
Tool Image	2
Mandatory Action and Personal Protection	
Identification	3
Product Safety Information	3
General Description	4
Inspection	4
Tool Assembly Instructions (before use	
steps).....	4
Operation Section	4
References	5

Introduction

This manual contains safety information, operation instructions, and maintenance information and should be stored with the tool group.

The information, specifications, and illustrations in this publication are based on information that was available at the time that the publication was written. The specifications, torques, pressures, measurements, adjustments, illustrations, and other items can change at any time. These changes can affect the service that is given to the product. Obtain the complete and most current information before you start any job.

Some photographs or illustrations in this publication may show details that can be different from your service tool due to updates. Guards and covers might have been removed for illustrative purposes.

Caterpillar cannot anticipate every possible circumstance that might involve a potential hazard. The warnings in this publication and on the product, are therefore, not all inclusive. If a tool, procedure, work method, or operating technique that is not recommended by Caterpillar is used, the operator is responsible for ensuring that the procedures used are safe. The operator must also be sure that the product will not be damaged or made unsafe by any unspecified procedures.

NOTICE

Illustration 1

g06350463

Do not operate or perform any lubrication, maintenance, or repair on this product until you have read and understand the operation lubrication, maintenance, and repair information.

When replacement parts are required for this product, Caterpillar recommends using Cat replacement parts or parts with equivalent specifications including, but not limited to physical dimensions, type, strength, and material.

Whenever a question arises regarding your service tool or this publication, contact the Global Dealer Solutions Network hotline at:

USA: 1-877-228-2420

International: 1-309-578-7372

Safety Information

Most accidents that involve product operation, maintenance, and repair are caused by failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing potentially hazardous situations before an accident occurs. The operator should also have the necessary training, skills, and tools to perform these functions properly.