## Parts Manual

## **Snow Wings**

G361-UP (Snow Wing) G371-UP (Snow Wing)





## Product and Dealer Information

Note: For product identification plate locations, see the section "Product Identification Information" in the Operation and Maintenance Manual.

| Delivery Da | ate:                 |              |              |  |  |  |
|-------------|----------------------|--------------|--------------|--|--|--|
| Produc      | t Information        |              |              |  |  |  |
| Model:      |                      |              |              |  |  |  |
| Product Ide | entification Number: |              |              |  |  |  |
| Engine Ser  | ial Number:          |              |              |  |  |  |
| Transmissio | on Serial Number:    |              |              |  |  |  |
| Generator   | Serial Number:       |              |              |  |  |  |
| Attachment  | Serial Numbers:      |              |              |  |  |  |
| Attachment  | Information:         |              |              |  |  |  |
| Customer I  | Equipment Number:    |              |              |  |  |  |
| Dealer Equ  | iipment Number:      |              |              |  |  |  |
| Dealer      | Information          |              |              |  |  |  |
| Name:       | Branch:              |              |              |  |  |  |
| Address:    |                      |              |              |  |  |  |
|             |                      |              |              |  |  |  |
|             |                      |              |              |  |  |  |
|             | Dealer Contact       | Phone Number | <u>Hours</u> |  |  |  |
| Sales: -    |                      |              |              |  |  |  |
| Parts: -    |                      |              |              |  |  |  |
| Service: -  |                      |              |              |  |  |  |