

# Parts Manual

---

## **518 Skidder**

---

**50S3230 to Last Built (Vehicle)**  
**94U691 to 94U740 (Vehicle)**  
**7Z1523 to Last Installed (Engine)**  
**3GA1 to Last Installed (Transmission)**

**Powered by 3304 Engine**

---