

Parts Manual



See "General Information"
for New Parts Manual
Features.

528B Wheel Skidder

8SJ1-99999 (Machine)
08Z66000-99999 (Engine)
1PX1-99999 (Transmission)
7GX1-99999 (Transmission)

Powered By 3306 Engine
