

Parts Manual



See "General Information"
for New Parts Manual
Features.

530B Wheel Skidder

5BK1-Up (Machine)
08Z66000-99999 (Engine)
6NC1-Up (Engine)
3PX1-99999 (Transmission)
7HX1-Up (Transmission)

Powered By 3306 Engine

A solid black horizontal bar at the bottom of the page.