

# Parts Manual

---

## Quick Couplers (Loaders, Tool Carriers)

---

7WW1-UP (Quick Coupler)  
APE1-UP (Quick Coupler)  
ARJ1-UP (Quick Coupler)  
ATH1-UP (Quick Coupler)  
BCJ1-UP (Quick Coupler)



# Product and Dealer Information

Note: For product identification plate locations, see the section “Product Identification Information” in the Operation and Maintenance Manual.

Delivery Date: \_\_\_\_\_

## Product Information

Model: \_\_\_\_\_

Product Identification Number: \_\_\_\_\_

Engine Serial Number: \_\_\_\_\_

Transmission Serial Number: \_\_\_\_\_

Generator Serial Number: \_\_\_\_\_

Attachment Serial Numbers: \_\_\_\_\_

Attachment Information: \_\_\_\_\_

Customer Equipment Number: \_\_\_\_\_

Dealer Equipment Number: \_\_\_\_\_

## Dealer Information

Name: \_\_\_\_\_ Branch: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

|          | <u>Dealer Contact</u> | <u>Phone Number</u> | <u>Hours</u> |
|----------|-----------------------|---------------------|--------------|
| Sales:   | _____                 | _____               | _____        |
| Parts:   | _____                 | _____               | _____        |
| Service: | _____                 | _____               | _____        |