

Parts Manual

CX35-P800-C27l Petroleum Power Train Package

TWM1-UP (Engine)
PCY1-UP (Package)
TRJ1-UP (Transmission)
T8J1-UP (Torque Converter)