



Operation and Maintenance Manual

Cast Manual Pin Grabber Coupler

XXF1-Up (307)
XXG1-Up (311/312)
XXH1-Up (315)
XXE1-Up (B)