



Operation and Maintenance Manual

RM-250C Reclaimer Mixer



Scan to find and purchase genuine Cat® parts and related service information.



Important Safety Information

Most accidents that involve product operation, maintenance and repair are caused by failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing potentially hazardous situations before an accident occurs. A person must be alert to potential hazards. This person should also have the necessary training, skills and tools to perform these functions properly.

Improper operation, lubrication, maintenance or repair of this product can be dangerous and could result in injury or death.

Do not operate or perform any lubrication, maintenance or repair on this product, until you have read and understood the operation, lubrication, maintenance and repair information.

Safety precautions and warnings are provided in this manual and on the product. If these hazard warnings are not heeded, bodily injury or death could occur to you or to other persons.

The hazards are identified by the "Safety Alert Symbol" and followed by a "Signal Word" such as "DANGER", "WARNING" or "CAUTION". The Safety Alert "WARNING" label is shown below.



The meaning of this safety alert symbol is as follows:

Attention! Become Alert! Your Safety is Involved.

The message that appears under the warning explains the hazard and can be either written or pictorially presented.

Operations that may cause product damage are identified by "NOTICE" labels on the product and in this publication.

Caterpillar cannot anticipate every possible circumstance that might involve a potential hazard. The warnings in this publication and on the product are, therefore, not all inclusive. If a tool, procedure, work method or operating technique that is not specifically recommended by Caterpillar is used, you must satisfy yourself that it is safe for you and for others. You should also ensure that the product will not be damaged or be made unsafe by the operation, lubrication, maintenance or repair procedures that you choose.

The information, specifications, and illustrations in this publication are on the basis of information that was available at the time that the publication was written. The specifications, torques, pressures, measurements, adjustments, illustrations, and other items can change at any time. These changes can affect the service that is given to the product. Obtain the complete and most current information before you start any job. Caterpillar dealers have the most current information available. For a list of the most current publication form numbers available, see the Service Manual Contents Microfiche, REG1139F.



When replacement parts are required for this product Caterpillar recommends using Caterpillar replacement parts or parts with equivalent specifications including, but not limited to, physical dimensions, type, strength and material.

Failure to heed this warning can lead to premature failures, product damage, personal injury or death.

Table of Contents

Foreword	4	Engine Starting	36
Safety Section		Operation	39
Safety Signs and Labels	6	Operating Techniques	41
General Hazard Information	7	Machine Service	48
Crushing Prevention and Cutting Prevention....	9	Parking	49
Burn Prevention	10	Machine Cleanup	50
Fire Prevention and Explosion Prevention	10	Transportation Information	51
Tire Information	12	Towing Information	53
Electrical Storm Injury Prevention	12	Maintenance Section	
Mounting and Dismounting	13	Torque Specifications	56
Before Starting Engine	13	Tire Inflation Information	59
Engine Starting	13	S·O·S Fluid Analysis	60
Before Operation	14	Lubricant Viscosities and Refill Capacities	62
Operation	14	Maintenance Interval Schedule	63
Parking	14	Reference Information Section	
Sound Information and Vibration Information .	15	Reference Materials	97
Product Information Section		Index Section	
General Information	16	Index	99
Model Views and Specifications	17		
Identification Information	18		
Operation Section			
Monitoring Systems and Operator Station Features	20		
Machine Controls	28		
Before Starting Engine	35		